

Apparel Material Selection Guide

For additional information, please see page 1550 for the Chemical Compatibility Chart for Apparel.

Tyvek® QC is a polyethylene-coated Tyvek fabric designed to provide splash protection from a mid-range of chemicals and particulates.

Kleenguard® apparel features unique outer layers made with spunbound polypropylene for extra strength and cloth-like comfort. Its melt blown middle layer is composed of an intricate matrix of microfibers acting as a filter to keep out many fine particulates and water-based liquids. Since it's breathable, both air and water vapor can pass through the garment to keep skin cool, reducing the risk of heat stress in hot environments.

NexGen™ is a microporous bi-laminate polyolefin composite. This nonwoven material is lightweight and soft, yet strong—whether wet or dry.

Pro/Shield® 1 is a tri-laminate spunbound-meltblown-spunbound polypropylene fabric. Because it's soft, lightweight, and breathable, Pro/Shield 1 is ideal for many situations where a dry particulate barrier and repellency are needed.

Pro/Shield® 2 is a material made of microporous film laminated to a non-woven polypropylene substrate. This unique material provides an excellent protective barrier, holding out 100% of all dry particles down to 0.19 microns while remaining breathable for maximum worker comfort.

DUPONT® Tyvek® QC Coveralls

Polyethylene-coated Tyvek® QC fabric provides splash protection from a mid-range of chemicals and particulates. Your comfort is ensured—coveralls have set-in sleeves and underarm gussets, extended-length torso, full-cut seat, and wide leg openings. Serged seams resist tears. All styles are yellow and have a front-zipper closure.

Ideal for:

- ▶ Acid handling
- ▶ Light chemical splash
- ▶ Mixing agrichemicals
- ▶ Oil refining

Description	Cat. no.	Size	Price
Coverall, zipper front, collar	A-86225-60	Medium	
	A-86225-61	Large	
	A-86225-62	X-large	
	A-86225-63	XX-large	
Coverall, zipper front, elastic wrists and ankles	A-86225-65	Medium	
	A-86225-66	Large	
	A-86225-67	X-large	
	A-86225-68	XX-large	
Coverall, zipper front, attached hood, skid-resistant boots, elastic wrists and face opening	A-86225-70	Medium	
	A-86225-71	Large	
	A-86225-72	X-large	
	A-86225-73	XX-large	



Coverall 86225-71 with attached skid-resistant boots and hood provides head to toe coverage.

Kleenguard coveralls**Kleenguard® and Kleenguard Ultra Coveralls****Designed for extended wear—breathable, lightweight, and strong!**

Kleenguard coveralls protect you from dry particulates and light liquid sprays. Kleenguard Ultra coveralls offer extra protection from liquids under pressure. Three-layer fabric includes a layer of microporous film so heat and sweat vapors escape—you can stay with the task at hand with less fatigue and heat stress!

The concealed front zipper measures at least 28" long. Three-thread overlap stitching improves strength and durability—easily put on and remove these coveralls without tearing them. It all adds up to comfortable, generously cut coveralls that are 7½ times less likely to rip out than the those made using the typical ANSI-standard design. Styles with elastic cuffs feature an elastic back waistband for improved fit and comfort.

Kleenguard coveralls are ideal for:

- ▶ Pharmaceuticals
- ▶ Maintenance/general clean-up
- ▶ Dusty environments
- ▶ Food processing

Kleenguard Ultra coveralls are ideal for:

- ▶ Liquid handling
- ▶ Tank cleaning
- ▶ Pressure washing
- ▶ Fiberglass handling

Kleenguard Ultra coveralls

Description	Catalog number				Price	
	Medium	Large	X-large	XX-large	1 ea	24 ea*
Kleenguard coveralls						
Coveralls	A-33670-80	A-33670-81	A-33670-82	A-33670-83		
Coveralls with elastic cuffs	A-33670-84	A-33670-85	A-33670-86	A-33670-87		
Coveralls with hood, elastic cuffs	A-33670-88	A-33670-89	A-33670-90	A-33670-91		
Coveralls with hood, boots, elastic cuffs	A-33670-92	A-33670-93	A-33670-94	A-33670-95		
Kleenguard Ultra coveralls						
Coveralls with elastic cuffs	A-33670-63	A-33670-64	A-33670-65	A-33670-66		
Coveralls with hood, elastic cuffs	A-33670-72	A-33670-74	A-33670-76	A-33670-78		
Coveralls with hood, boots, elastic cuffs	A-33670-67	A-33670-68	A-33670-69	A-33670-70		

***Save when you buy more!**

Save 10% on 24 or more coveralls of any combination of sizes or styles.